



SAFARI V-SPEC SNORKEL

SS1050HF

05/02/03

ITEM	DESCRIPTION	QTY	PART NO
1	BODY - Snorkel	1	955-133-000
2	3" AIR RAM ASSEMBLY	1	000-135-050
3	BRACKET - Upper Mounting	1	955-032-000
4	BOLT-HEX 6mm x 1.0mm x 14mm	2	000-002-100
5	SCREW -S/T 4.2mm x 13mm	4	000-951
6	BODY CLIP - PLASTIC	3	000-960
7	STUD - S/S 8mm x 1.25mm x 25mm O/L	2	000-110
8	WASHER -BODY 8mm x 30mm	2	000-311-300
9	NUT - NYLOC 8mm x 1.25mm	2	000-205-300
10	CLAMP - HOSE 50/70mm	2	000-906
11	HOSE - FLEXIBLE 63mm ID x 1100mm	1	000-883-110
12	ADAPTOR - AIR ENTRY	1	955-023-000
13	BLANK OFF PLATE - AIR INLET	1	955-025-000
14	BOLT – HEX 6mm x 1.0mm x 16mm	1	000-002
15	WASHER – BODY 6mm x 16mm	2	000-310-100
16	NUT – NYLOC 6mm x 1.0	1	000-204
17	POP RIVET 4mm x 12mm	9	000-958
18	RUBBER EDGING 300mm	2	000-953-030
19	CABLE TIE	2	000-987-365
20	TEMPLATE	1	955-017-000
21	TEMPLATE - AIR CLEANER	1	955-017-200
22	HOSE CLAMP-SIZE 48 (BLACK)	1	000-918/B

WARNING!!

**IT IS AN INSTALLER
RESPONSIBILITY TO VERIFY
ALL COMPONENTS, AND
PARTICULARLY THE
TEMPLATE ARE CORRECT,
BEFORE STARTING ANY PART
OF THE SNORKEL
INSTALLATION.**

**(CHECK TEMPLATE AGAINST
SNORKEL BODY)**



SAFARI V-SPEC SNORKEL

SS1050HF

JEEP JT WRANGLER 4L PETROL ENGINE (PRE September '99)

Fitment to: Right hand side

Fitting time: Approximately 120 minutes

Special tools: 76mm Holesaw
Air Hacksaw
Step Drill
Pop Rivet Gun

Instructions:

1. Remove: Air cleaner assembly
Tray under Brake Booster (RHD Models)
Vacuum Reservoir
Wrangler Sticker
2. Positioning the template along the join of the guard to the body, place a flat item (eg 30cm ruler) along the top of the guard butting the template up square. Tape the template to the guard. Using a felt tip pen, mark all hole positions, remove the template.
3. Drill a pilot hole for each hole position. Using the step drill, drill the 2 snorkel mounting hole positions to 12mm, using the 76mm holesaw drill the main hole, de-burr and paint all holes.

NEW ZEALAND INSTALLATIONS ONLY :

Safari have developed 2 methods of Snorkel A pillar attachment, for the conventional method please proceed with the current document alternatively please see the link below for further instructions.

www.safari4x4.co.nz/apillarmounting

4. Screw the mounting studs into the snorkel body inserts, fasten the upper mounting bracket to the snorkel body. Place a piece of masking tape along the 'A' pillar approximately where the bracket will be positioned. Carefully position the snorkel body onto the guard. With the snorkel body correctly positioned onto the body, mark around the outside of the bracket. Remove the snorkel body.
5. Remove the 'A' pillar bracket from the snorkel body and position onto the 'A' pillar between the outlined marks, using a felt tip pen mark the hole positions, drill a pilot hole for each position and then drill to 8mm. De-burr and paint holes.
6. Insert plastic body clips into the 'A' pillar, fasten 'A' pillar bracket into position using S/T screws (item no. 5). Position the snorkel body onto the guard with the snorkel body correctly positioned fasten using necessary hardware.
7. Remove the air entry snout from the air cleaner housing, tape the air cleaner template into position, mark all holes and the cut out section. Drill a 5mm hole for each hole position, using the air hacksaw cut out the new air entry hole. Place the air inlet blank off plate (item no. 13) into position and mark each hole position, drill each hole to 5mm.
8. Apply a liberal amount of silicone sealant (sensor) to the blank off plate and pop rivet to the air cleaner housing. Apply a liberal amount of silicone sealant to the air inlet adaptor and pop rivet into position.
9. Fit rubber edging into position (refer drawing) re-install air cleaner housing to vehicle, install flexible ducting and fasten using the cable ties supplied position the ducting as per drawing. Refit tray under brake booster and vacuum reservoir.
10. Install air ram assembly to the snorkel body and fasten.

WARNING: IT IS THE INSTALLER'S RESPONSIBILITY TO ENSURE ALL CONNECTIONS ARE WATER TIGHT.

SAFARI

4X4 ENGINEERING

Model No: SS 1050HF 27/6/00
 Description: JEEP TJ WRANGLER 4L PETROL ENG.
 Sub Assembly: SAFARI SNORKEL

